





# oscar oscar tondo



# GLOBAL provides a 10 year warranty from the production date

(stamped on the side of each sections) The conventional warranty grants the sole right to free replacement of the radiator which, due to defects originating from defects in material or wokmanship, is not fit for purpose or its ordinary intended use. Replacement radiators shall be delivered free of charge to the retailer who sold the radiator to the end customer or his installer.

The warranty is valid on the condition that the installation and the system to which the product is connected are performed by qualified/authorised personnel to top workmanship standards and in compliance with the regulations and requirements of the sector in force; it is also valid on the condition that there has been full compliance with warnings and instructions for proper installation, use and maintenance of the product indicated in the technical documentation under the paragraph entitled *correct installation*, use and maintenance instructions, available and downloadable from the *TECHNICAL INFO* section on the **globalradiatori.it** website. The warranty is regulated by further conditions indicated in the technical catalogue and the CONVENTIONAL WARRANTY section on the globalradiatori.it website.



**HIGH THERMAL OUTPUT** Guaranteed by certification, according to the norm EN 442, from the *Politecnico* in Milan. The high thermal output allows less bulky radiators to be installed.

**ENERGY SAVING WITH MAXIMUM COMFORT** With the Global radiators the regulation of the temperature is easy and inexpensive. An ideal temperature for every environment according to personal needs is rapidly achieved.

**VERY LONG DURATION** Thanks to the high quality of the material, that gives the maximum guarantee of resistance and duration. The double protection in the "anaphoresis-bath" followed with epoxy power enameling guarantees a perfect and durable finish.

**EASIER INSTALLATION** Due to the lightness of the aluminum and the sectional elements that allow greater ease and flexibility of installation.

**CERTIFIED QUALITY AND ENVIRONMENTAL** The ICIM certified on 1994 (norm ISO 9001:2000) the Quality System and on 2001 (norm UNI EN ISO 14001) the System of Environmental Management.




Model l		dimensions mm				Ø	dry	water	heat output EN 442			
		Α	В	С		connec-	weight approx.	content	ΔT 50°C	ΔT 30°C	exponent	coefficient
		overall height	eight width depth		pipe centres	tion	Kg	litres	Watts	Watts	<u> </u>	1
OSCAR	2000	2046	80	95	2000	1"	3,86	0,76	321	161	1,35280	1,61490
OSCAR	1800	1846	80	95	1800	l 1"	3,53	0,69	297	148	1,35295	1,48966
OSCAR	1600	1646	80	95	1600	1 1"	3,18	0,62	271	136	1,35310	1,36136
OSCAR	1400	1446	80	95	1400	1 1"	2,80	0,56	245	123	1,35325	1,23096
OSCAR	1200	1246	80	95	1200	1 1"	2,43	0,49	218	109	1,35340	1,09584
OSCAR	1000	1046	80	95	1000	1 1"	2,05	0,42	190	95	1,35355	0,95514
OSCAR	900	946	80	95	900	1"	1,99	0,41	175	88	1,34630	0,90160
OSCAR TONDO	2000	2046	80	95	2000	1"	3,86	0,76	321	161	1,35280	1,61490
OSCAR TONDO	1800	1846	80	95	1800	1"	3,53	0,69	297	148	1,35295	1,48966
OSCAR TONDO	1600	1646	80	95	1600	1"	3,18	0,62	271	136	1,35310	1,36136
OSCAR TONDO	1400	1446	80	95	1400	1 1"	2,80	0,56	245	123	1,35325	1,23096
OSCAR TONDO	1200	1246	80	95	1200	1"	2,43	0,49	218	109	1,35340	1,09584
OSCAR TONDO	1000	1046	80	95	1000	1"	2,05	0,42	190	95	1,35355	0,95514
OSCAR TONDO	900	946	80	95	900	'	1,99	0,41	175	88	1,34630	0,90160

<sup>\* 1</sup> Watt = 0,863 Kcal/h

The heat output is certified in according to the norm EN 442.







# EXAMPLE FOR A DIFFERENT ΔT FROM ΔT 50°C

If you need to know a radiator heat output (P) with different  $\Delta T$  from  $\Delta t$  50°C, use the following characteristic equation: P=Km  $\cdot \Delta T^n$  Example for the Oscar 1600 model with  $\Delta T = 60$ °C P= 1,36136  $\cdot 60^{1,35310} = 347$  Watt

# EXAMPLE OF HEAT OUTPUT READINGS WITH DIFFERENT $\Delta$ T FROM $\Delta$ T 50°C

Model		ΔT 20°C	ΔT 25°C	ΔT 30°C	ΔT 35°C	ΔT 40°C	ΔT 45°C	ΔT 50°C	ΔT 55°C	ΔT 60°C
OSCAR	2000	93	126	161	198	237	278	321	365	411
OSCAR	1800	86	116	148	183	219	257	297	337	379
OSCAR	1600	78	106	136	167	200	235	271	308	347
OSCAR	1400	71	96	123	151	181	213	245	279	314
OSCAR	1200	63	85	109	135	161	189	218	248	279
OSCAR	1000	55	75	95	118	141	165	190	217	244
OSCAR	900	51	69	88	108	129	152	175	199	223
OSCAR TONDO	2000	93	126	161	198	237	278	321	365	411
OSCAR TONDO	1800	86	116	148	183	219	257	297	337	379
OSCAR TONDO	1600	78	106	136	167	200	235	271	308	347
OSCAR TONDO	1400	71	96	123	151	181	213	245	279	314
OSCAR TONDO	1200	63	85	109	135	161	189	218	248	279
OSCAR TONDO	1000	55	75	95	118	141	165	190	217	244
OSCAR TONDO	900	51	69	88	108	129	152	175	199	223

The expected heat output is obtained by observing the distances specified below:

- ≥ cm 3 from the wall
- ≥ cm 10 from the floor
- ≥ cm 10 from the shelf or window-sills

In order to prevent the thermal expansion of the system from causing noise in correspondence with the heaters, it is advisable to use plastic brackets to support the radiators (items A004, A025, A027 or A029 in our catalogue).






#### CORRECT INSTALLATION, USE AND MAINTENANCE INSTRUCTIONS

- The Oscar and Oscar Tondo radiators can be used in all hot water or vapour heating installations up to 110°C with a working pressure up to 1600 K Pascal - 16 bar.
- \* They can be installed in systems with iron, copper or thermoplastic pipes.
- \* In order to protect the system from scaling and corrosion processes, which affect radiators, pipes and boilers, the INI-CTI 8065 Standard provides for the treatment of the filling water of the system, without distinguishing between aluminium, steel or cast iron.
- \* Among the various products to be added to the system in accordance with the abovementioned UNI Standard, there is a specific one for aluminium, an aliphatic film-forming polyamine marked under the name Cillit-HS 23 Combi (recommended dosage: 1 litre for every 200 litres of water circulating in the system). However, it is useful to check the pH value of the water, which should preferably be between 6.5 and 8.
- \* It is recommended to install automatic air vent valves on each radiator.
- \* Avoid closing the radiator shut-off valves completely in order to allow any gas that may be inside the radiators to escape through the automatic air vent valve that is compulsory in every heating system, thus avoiding possible overpressure that could damage the radiators.
- \* If one or more batteries are to be excluded from the circuit, an automatic air vent must be fitted to each battery.
- \* For a good preservation of the paint, it is necessary that the radiators, before and after installation, are not kept in very humid environments (inside showers, in saunas, in Turkish baths, near swimming pools, etc.). If paint comes off at one point on the radiator, aluminium oxide con from and cause the paint to peel off completely. Do not use porous clay humidifiers.
- \* To clean the outside of the radiator, do not use abrasive or chemically corrosive/aggressive products of any kind, as the use of water and neutral detergents is sufficient and the operation must be carried out when the radiator is cold to preserve the original brillance of the paint over time.
- \* Do not place weights and/or objects on the radiators. Do not use radiators for any purpose other than as a heater (e.g.: as a bench/stand, ladder, to store furniture or objects).

# ADDITIONAL NOTES FOR OSCAR AND OSCAR TONDO


\* Important: if the Oscar and Oscar Tondo radiators are connected hydraulically with the connections at the bottom on opposite sides, it is useful to insert a diverter (art. A022) between the first and the second section.

This prevents abnormal circulation of the thermal fluid, thus guaranteeing maximum performance of the heater.





# accessories



A011 galvanized straight bracket



ANGLE BRACKET A003 galvanized A003 white plastic



A025 plug bracket white (pair) A026 170 mm whit expansion plug bracket special colours (pair)



A027 universal brackets white blister pack (pair)



square brackets white blister pack (pair)



A024 O-ring gasket for Ekos Plus, Oscar, Oscar Tondo, Junior



A017 RAL 9010 white marker



A237 white handy grip A238 chrome handy grip



**TOWEL RAILS** A201 48 cm white A202 48 cm chrome A207 32 cm white A208 32 cm chrome



SIDE PANEL RAL 9010 WHITE A061 mod. 1000 A062 mod. 1200 A063 mod. 1400 A064 mod. 1600 A065 mod. 1800 A066 mod. 2000



A022 diverter for Oscar, Oscar Tondo, Ekos Plus



A010 RAL 9010 white spray can A010 special colours spray can



REDUCER KIT WITH SILICONE GASKETS AND ADJUSTABLE VALVE

A043 3/8" for 200/D radiators -800 mm white or chrome 3/8" for 900 to 2000 mm radiators and Junior white or chrome

A046 1/2" for 200/D radiators -800 mm white, chrome or special colours

A047 1/2" for 900 to 2000 mm radiators and Junior, white, chrome or special colours

A048 3/4" for 200/D radiators -800 mm white or chrome

3/4" for 900 to 2000 mm radiators and Junior, white or chrome



A009 1" nipple



A018 Cillit HS 23 Combi liquid





valve - chrome

A042 1/2" automatic air vent

1"BLIND PLUG OR REDUCER

A013 1" float type air vent

MANUAL AIR VENT VALVE

A041 1/2" adjustable manual

air vent valve - white

A012 1/8"

A039 1/4"

A040 3/8"

valve right or left

white with silicone gasket

A005 white A006 galvanized

A020



A038 1/2" adjustable manual air vent valve - chrome



A019 plug wrench

standard colour special colours see the Colour Card

cod. 10 white glossy

white sand RAL 9010 RAL 9016

cod 11

cod. 01 ivory glossy **RAL 1013** 

cod. 05 metallic matt beige 2589

cod. 06 metallic matt quartz 2921

cod. 07 metallic matt dark grey 2748

A079 hex key with lever

A080 hex key 500 mm

A081 hex key 800 mm

cod. 08 metallic matt silver grey 2676

cod. 09 metallic matt rust 3112



GLOBAL di Fardelli Ottorino & C. s.r.l.

24060 ROGNO (BG) ITALIA • via Rondinera, 51 tel. ++39 035977111 • fax ++39 035977110 globalradiatori.it • info@globalradiatori.it



