LOVERE

ALUMINIUM RADIATORS







GLOBAL provides a 10 year warranty from the production date

(stamped on the side of each sections)
The conventional warranty grants the sole right to free replacement of the radiator which, due to defects originating from defects in material or wokmanship, is not fit for purpose or its ordinary intended use. Replacement radiators shall be delivered free of charge to the retailer who sold the radiator to the end customer or his installer.

The warranty is valid on the condition that the installation and the system to which the product is connected are performed by qualified/authorised personnel to top workmanship standards and in compliance with the regulations and requirements of the sector in force; it is also valid on the condition that there has been full compliance with warnings and instructions for proper installation, use and maintenance of the product indicated in the technical documentation under the paragraph entitled *correct installation*, use and maintenance instructions, available and downloadable from the *TECHNICAL INFO* section on the **globalradiatori.it** website. The warranty is regulated by further conditions indicated in the technical catalogue and the CONVENTIONAL WARRANTY section on the **globalradiatori.it** website.

LOVERE	dimensions mm					dry weight	water	heat output EN 442			
	A overall height	B width	C depth	D pipe centres	connection	approx. Kg	content litres	ΔT 50°C	ΔT 30°C	exponent n	coefficient Km
								Watt	Watt		
800	875	80	95	800	1"	1,80	0,61	160	81	1,32708	0,88901
700	775	80	95	700	1"	1,60	0,55	143	73	1,31451	0,83571
600	675	80	95	600	1"	1,40	0,51	127	65	1,30194	0,77624
500	575	80	95	500	1"	1,20	0,46	110	57	1,28800	0,71350
350	425	80	95	350	1"	0,93	0,37	82	43	1,26969	0,57402

^{* 1} Watt = 0,863 Kcal/h

The heat output is certified by the Institute of Engineering *Politecnico* in Milan according to the norm EN 442.

24 EN 442

EXAMPLE FOR A DIFFERENT ΔT

If you need to know a radiator heat output (P) with different ΔT from Δt 50°C, use the following characteristic equation: P=Km · ΔT^n Example for the 600 model with $\Delta T = 60$ °C \rightarrow P= 0,77624 · 60^{1,30194} = 161 Watt



LOVERE	ΔT 20°C	ΔT 25°C	ΔT 30°C	ΔT 35°C	ΔT 40°C	ΔT 45°C	ΔT 50°C	ΔT 55°C	ΔT 60°C
800	47	64	81	99	119	139	160	181	203
700	43	57	73	89	107	125	143	162	182
600	39	52	65	80	95	111	127	144	161
500	34	45	57	69	82	96	110	124	139
350	26	34	43	52	62	72	82	93	104


The expected heat output is obtained by observing the distances specified below:

- ≥ cm 2 from the wall
- ≥ cm 10 from the floor
- ≥ cm 10 from the shelf or window-sills

In order to prevent the thermal expansion of the system from causing noise in correspondence with the heaters, it is advisable to use plastic brackets to support the radiators (items A004, A025, A027 or A029 in our catalogue).

CORRECT INSTALLATION, USE AND MAINTENANCE INSTRUCTIONS

- ★ Lovere radiators can be used in all hot water or vapour heating installations up to 110°C with a working pressure up to 1600 K Pascal 16 bar.
- ★ They can be installed in systems with iron, copper or thermoplastic pipes.
- ★ In order to protect the system from scaling and corrosion processes, which affect radiators, pipes and boilers, the INI-CTI 8065 Standard provides for the treatment of the filling water of the system, without distinguishing between aluminium, steel or cast iron.
- ★ Among the various products to be added to the system in accordance with the abovemen tioned UNI Standard, there is a specific one for aluminium, an aliphatic film-forming polyamine marked under the name Cillit-HS 23 Combi in the quantity recommended by the manufacterer. However, it is useful to check the pH value of the water, which should preferably be between 6.5 and 8.
- ★ It is recommended to install automatic air vent valves on each radiator.
- ★ Avoid closing the radiator shut-off valves completely in order to allow any gas that may be inside the radiators to escape through the automatic air vent valve that is compulsory in every heating system, thus avoiding possible overpressure that could damage the radiators.
- ★ If one or more batteries are to be excluded from the circuit, an automatic air vent must be fitted to each battery.
- ★ For a good preservation of the paint, it is necessary that the radiators, before and after installation, are not kept in very humid environments (inside showers, in saunas, in Turkish baths, near swimming pools, etc.). If paint comes off at one point on the radiator, aluminium oxide con from and cause the paint to peel off completely. Do not use porous clay humidifiers.
- ★ To clean the outside and surfaces near the radiator, it is necessary to avoid the use of abrasive or chemically corrosive/aggressive products of any nature: we recommend water and neutral cleaning. The operation must be carried out when the radiator is cold to preserve the original brillance of the paint over time.
- ★ Do not place weights and/or objects on the radiators. Do not use radiators for any purpose other than as a heater (e.g.: as a bench/stand, ladder, to store furniture or objects).





ACCESSORIES





ANGLE BRACKET A003 galvanized A004 white plastic



special colours (pair)


EXPANSION PLUG BRACKETS A025 170 mm white or special colours (pair) A026 195 mm white or



Δ027 universal brackets white blister pack (pair)



A029 square brackets white blister pack (pair)





A015 white floor fixing system



A237 white handy grip A238 chrome handy grip



TOWEL RAILS A201 48 cm white A202 48 cm chrome A207 32 cm white A208 32 cm chrome



A010 RAL 9010 white or special colours spray can



A017 RAL 9010 white marker



REDUCER KIT WITH SILICONE GASKETS AND ADJUSTABLE VALVE A043 3/8" for 200/D radiators

- 800 mm - white or chrome 1/2" for 200/D radiators

- 800 mm - white, chrome, special colours

A048 3/4" for 200/D radiators - 800 mm - white or chrome



REDUCER KIT WITH SILICONE GASKETS AND VALVE WHIT HANDWHEEL

A190 3/8" for 200/D radiators - 800 mm - white

A192 1/2" for 200/D radiators - 800 mm - white



A009 1" nipple



Combi liquid



A079 hex key with lever A080 hex key 500 mm A081 hex key 800 mm





1" BLIND PLUG OR REDUCER

A005 white A006 galvanized

A020 white with silicone gasket



GASKETS

A007 1" plug 1,50 mm A008 1" nipple 1,00 mm A021 silicone - for plugs and reducers



A013 1" float type air vent valve right or left



MANUAL AIR VENT VALVE A012 1/8" A040 3/8 A039 1/4" A050 1/2"



A041 1/2" adjustable manual air vent valve - white



A042 1/2" automatic air vent valve - chrome



A038 1/2" adjustable manual air vent valve - chrome



A019 plug wrench



white glossy

RAL 9010



RAL 9016

white matt



cod. 01 ivory glossy **RAL 1013**

cod. 05 metallic matt beige



matt

quartz

cod. 06 cod. 07 metallic metallic



matt

dark grey

cod. 08 metallic



matt

silver grey

cod. 09 metallic matt rust



cod. 14 black matt



special colours see the Colour Card

The colours are indicative. For technical printing reasons, it is no possible to faithfully reproduce the paints used. The colour of the products supplied may differ from that shown in this catalogue.







